

MODE	PVLV	PMP2 OUT	PMP1 OUT	MOTOR +
RUN HI (AUTO)	~12V	0	~12V	~12V
RUN LO (AUTO)	~12V	~12V	0	~8V
FLUSH (AUTO)	~12V	0	0	~5V
RUN (MANUAL)	0	0	~12V	~12V
SERVICE (MANUAL)	~12V	0	0	~5V



Triggers from MPC/Connect Board

Output response based on trigger